

§§ 265.342—265.344 [Reserved]

§ 265.345 General operating requirements.

During start-up and shut-down of an incinerator, the owner or operator must not feed hazardous waste unless the incinerator is at steady state (normal) conditions of operation, including steady state operating temperature and air flow.

§ 265.346 [Reserved]

§ 265.347 Monitoring and inspections.

The owner or operator must conduct, as a minimum, the following monitoring and inspections when incinerating hazardous waste:

(a) Existing instruments which relate to combustion and emission control must be monitored at least every 15 minutes. Appropriate corrections to maintain steady state combustion conditions must be made immediately either automatically or by the operator. Instruments which relate to combustion and emission control would normally include those measuring waste feed, auxiliary fuel feed, air flow, incinerator temperature, scrubber flow, scrubber pH, and relevant level controls.

(b) The complete incinerator and associated equipment (pumps, valves, conveyors, pipes, etc.) must be inspected at least daily for leaks, spills, and fugitive emissions, and all emergency shutdown controls and system alarms must be checked to assure proper operation.

[46 FR 7678, Jan. 23, 1981, as amended at 47 FR 27533, June 24, 1982]

§§ 265.348—265.350 [Reserved]

§ 265.351 Closure.

At closure, the owner or operator must remove all hazardous waste and hazardous waste residues (including but not limited to ash, scrubber waters, and scrubber sludges) from the incinerator.

[*Comment:* At closure, as throughout the operating period, unless the owner or operator can demonstrate, in accordance with § 261.3(d) of this chapter, that the residue re-

moved from his incinerator is not a hazardous waste, the owner or operator becomes a generator of hazardous waste and must manage it in accordance with all applicable requirements of parts 262 through 266 of this chapter.]

§ 265.352 Interim status incinerators burning particular hazardous wastes.

(a) Owners or operators of incinerators subject to this subpart may burn EPA Hazardous Wastes FO20, FO21, FO22, FO23, FO26, or FO27 if they receive a certification from the Assistant Administrator for Solid Waste and Emergency Response that they can meet the performance standards of subpart O of part 264 when they burn these wastes.

(b) The following standards and procedures will be used in determining whether to certify an incinerator:

(1) The owner or operator will submit an application to the Assistant Administrator for Solid Waste and Emergency Response containing applicable information in §§ 270.19 and 270.62 demonstrating that the incinerator can meet the performance standards in subpart O of part 264 when they burn these wastes.

(2) The Assistant Administrator for Solid Waste and Emergency Response will issue a tentative decision as to whether the incinerator can meet the performance standards in subpart O of part 264. Notification of this tentative decision will be provided by newspaper advertisement and radio broadcast in the jurisdiction where the incinerator is located. The Assistant Administrator for Solid Waste and Emergency Response will accept comment on the tentative decision for 60 days. The Assistant Administrator for Solid Waste and Emergency Response also may hold a public hearing upon request or at his discretion.

(3) After the close of the public comment period, the Assistant Administrator for Solid Waste and Emergency Response will issue a decision whether or not to certify the incinerator.

[50 FR 2005, Jan. 14, 1985]